



Samsung NX1 Viewfinder Focus Dial Replacement

Replace the viewfinder focus dial on a Samsung NX1.

Written By: Hannah Patrick



INTRODUCTION

The viewfinder focus dial changes the blurriness or clarity of what you see through the viewfinder.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Viewfinder Focus Dial



- Push the rubber viewfinder grip upward.

Step 2



- Use the Phillips #00 screwdriver to remove one 6.4 mm screw in the center of the dial.
- Remove the dial by lifting upward with your fingers.

To reassemble your device, follow these instructions in reverse order.