



External battery Disassembly

Written By: kuhndawg25





TOOLS:

- [Heat Gun](#) (1)
 - [Jimmy](#) (1)
-

Step 1 — External battery Disassembly



- IFIXIT Battery pack
 - You'll need to use a heat gun to heat the adhesive
- ⚠ Heat the top of the pack for 2-3 minutes. Be careful when touching the pack after heating

Step 2



- Take the Jimmy and slide it in the groove and gently pry up and slowly work the jimmy down and around the pack
- Once done, you will see the adhesive.
- Clean the remaining adhesive off the battery pack

This document was generated on 2020-11-14 02:11:31 AM (MST).

To reassemble your device, follow these instructions in reverse order.