




# Dell E193FPc Interface Buttons Replacement

Replace the interface buttons if they have...

Written By: Charley Grove



---

## INTRODUCTION

Replace the interface buttons if they have fallen out or are worn out from usage.

---

### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
  - [iFixit Opening Tool](#) (1)
-

## Step 1 — Stand



- Lay the monitor screen-down so the back screws are exposed.
- Remove the four 11.9 mm Phillips #2 screws securing the stand to the back of the monitor.

## Step 2



- Gently lift and pull away the stand at a slight angle away from the monitor.

### Step 3 — Display Bezel



- Locate the two holes on the bottom of the monitor.
- Insert a plastic opening tool or spudger into the holes and gently pry the plastic apart along the groove.
- ⓘ This task is much easier if two people pry simultaneously at each hole.
- Continue prying along the entire edge of the monitor.

## Step 4





- When finished prying, the plastic will partially fall away from the rest of the monitor.

**⚠ Do not try to fully remove the front frame yet. The frame is still attached to the buttons.**


- While holding the frames together, carefully flip the monitor over so it faces screen down.
- Gently lift and remove the rear case from the monitor.

## Step 5



- Locate the green interface button board.
- Remove the three 9.71 mm Phillips #2 screws holding the interface button board to the display bezel.
- Lift the monitor interior away from the front cover.

## Step 6 — Interface Buttons



- Behind the front panel of the plastic cover lies the button strip.
- Remove the buttons by gently pulling up on the strip.
- ⓘ You may have to pry the plastic strip up with a prying tool or spudger to remove it.

To reassemble your device, follow these instructions in reverse order.