


# Samsung Galaxy Note 10.1 2014 Motherboard Replacement

Use this guide to replace a nonfunctional motherboard in your Samsung Galaxy Note 10.1 2014 edition.

Written By: Joseph Rasico



This document was generated on 2020-11-28 05:43:35 AM (MST).

# **INTRODUCTION**

This guide will teach how to replace the motherboard in your Samsung Galaxy 10.1 2014 edition.



# **TOOLS:**

- Black Nylon Spudger (1)
- Metal Spudger (1)
- Phillips #000 Screwdriver (1)



#### **PARTS:**

 Galaxy Note 10.1 (2014, Wi-Fi) Motherboard (1)


#### Step 1 — Case






- Using the <u>nylon spudger</u> or <u>plastic opening tool</u> along the edges of the screen, separate the back case off of the device.
- (i) If possible, consider using the black nylon spudger for a gentler separation.

#### Step 2 — Loudspeaker Modules





- Remove the three 3mm screws on the top right side of the device with the Phillips PH000 screw head.
- Remove the one 3mm screw on the top left side of the device with the same method.

## Step 3 — loudspeaker - remove right speaker









- Remove the gray rubber piece.
- Use a spudger or fingernail to disconnect the blue antenna cable from the motherboard.
- Remove the right speaker unit.

## Step 4









- Remove the loudspeaker modules located on the parts where the screws were removed by using the black nylon spudger.
- They are the black pieces at the top left and right corners of the device that have metal squares on them in the middle.

## Step 5 — Battery




- Place your finger on the thin black bar at the end of the ribbon tape and flip each one up.
- Gently pull the ribbon tape on the battery away from the bar. Repeat this process for the second ribbon tape.


# Step 6



 Remove the six 3mm screws around the battery with the <u>Phillips PH000</u> <u>screwdriver</u>.


# Step 7





- Lift up the battery from the bottom and situate the <u>black nylon spudger</u> underneath the battery.
- Use the black nylon spudger to disconnect the multi-colored wires from the rest of the device.

#### Step 8 — Motherboard







- Disconnect all cables on the motherboard.
- (i) See our connector guide for help safely disconnecting various types of connectors.

#### Step 9







- Use the black nylon spudger to gently lift the motherboard away from the frame.
- Remove the motherboard.

To reassemble your device, follow these instructions in reverse order.