



# Emson Star Wars R2-D2 Water Tank Valve Replacement

This guide demonstrates the steps required to replace the valve situated on the water tank of the R2-D2 Humidifier.

Written By: Yash Chari



---

## INTRODUCTION

The valve allows water to move through the device in order for the water to be vaporized and ultimately emitted. If the device doesn't emit vapor or leaks, the water valve may not be functioning properly. It may also be possible that it isn't attached tightly enough. We will demonstrate the steps to take out the valve and then replace it.



### TOOLS:

- [Fingers](#) (1)
-

## Step 1 — Water Tank Valve



- Gently lift the cover off the humidifier.

## Step 2



- Gently pull the water tank off the base.

### Step 3



- Locate the valve at the bottom of the tank.
- Twist counterclockwise to remove the valve.

To reassemble your device, follow these instructions in reverse order.