



Dell Inspiron 910 Keyboard Replacement

This guide will teach you how to remove the...

Written By: Kyle Beekman



INTRODUCTION

This guide will teach you how to remove the keyboard on a Dell Inspiron 910.

TOOLS:

[Phillips #00 Screwdriver](#) (1)

[iFixit Opening Tool](#) (1)

Step 1 — Battery



- Flip the laptop so the battery is facing upwards.
- Push the battery release tabs toward the center of the device.
- Remove the battery.

Step 2 — Keyboard



- Remove the two countersunk keyboard screws using the Phillips #00 screwdriver.

Step 3



- Lift up the keyboard using your fingers or a plastic opening tool.
- ⚠ Potential for device damage: Do not tear the ribbon cable hidden behind the keyboard.
- Disconnect the cable by sliding the connector ears outward.

To reassemble your device, follow these instructions in reverse order.