



# Dyson Ball Animal Hose Replacement

Description of how to remove the wand hose for replacement

Written By: Mitchell Klein



---

## INTRODUCTION

This guide will show how to remove the wand hose in case of a clog, broken seal or other malfunction.



### PARTS:

- [Dyson DY-920765-04 Hose](#) (1)
-

## Step 1 — Hose



- Turn off power and unplug the vacuum, then turn the vacuum to look at the hose.

## Step 2



- Turn the red dial counterclockwise and pull up on the wand to remove.

### Step 3



- Press in the red button where the wand attaches to the hose and pull apart.

### Step 4



- Remove the main canister by pressing the red release button and pulling up and away.

## Step 5



- Grip the base of the hose so your thumb reaches around to press the red tab shown.
- Push the red tab at towards the hose while pulling the hose upwards.
- ⓘ With some wiggling, it will come out.

To reassemble your device, follow these instructions in reverse order.