



iMac G5 17" Model A1144 Access Door Replacement

Written By: Walter Galan



INTRODUCTION

Remove your access door to replace RAM chips or to gain access to your iMac's internals.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Access Door



⚠ Before you work on the computer, unplug the computer and press the power button for 20-30 seconds to drain the stored energy in the power supply.

- Loosen the two Phillips screws securing the access door to your iMac.

i These screws are captive in the access door.

Step 2



- Remove the access door from your iMac.

To reassemble your device, follow these instructions in reverse order.