Dell Inspiron n5110 - RAM Memory Replacement / Upgrade

Written By: ZFix

This document was generated on 2020-12-02 09:26:29 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 3

INTRODUCTION

How to change or upgrade your RAM memory.

Please SUBSCRIBE to my channel ツ

[video: http://youtu.be/Tjo2cGmfRpg]

🔧 TOOLS:

- iFixit Opening Tools (1)
- Phillips #0 Screwdriver (1)

⚙ PARTS:

- DDR3 1333 SO-DIMM RAM (1)

This document was generated on 2020-12-02 09:26:29 AM (MST).

Step 1 — RAM Memory

- Switch off the laptop and remove the battery.

- Remove the RAM memory cover.

Step 2

- By using plastic tool unlock the memory module.

- Hold the board by the corners !

- .

📌 **Please SUBSCRIBE to my channel ツ**

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-12-02 09:26:29 AM (MST).