



Resealing Procedure

Use this guide to close and reseal your Apple...

Written By: Dominik Schnabelrauch



INTRODUCTION

Use this guide to close and reseal your Apple Watch Series 4 after disassembly.

TOOLS:

ESD Safe Blunt Nose Tweezers (1)

iOpener (1)

Step 1 — Resealing Procedure



- Remove the blue protective film from the adhesive.
- ① To simplify the removal you can lift and cut the blue protective film at one point. Avoid cutting the force touch gasket.

Step 2



- Align the screen and press it down firmly onto the adhesive.
- For best results, apply heat from your iOpener, heat gun, or hair dryer to help set the adhesive.
- After the screen sits in place apply some pressure for a few hours by wrapping the watch with a couple rubber bands, or placing it under a heavy book or two.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Check out our [Answers community](#) for troubleshooting help.