



# Dell XPS 13 9365 2-in-1 Battery Replacement

Use this guide to remove or replace the battery for the Dell XPS 13 9365 2-in-1 laptop.

Written By: Johnathan Hammond



## INTRODUCTION

This guide shows how to remove and replace the battery for the Dell XPS 13 9365 2-in-1 laptop. Always remove your laptop battery first before doing any work inside your laptop, and follow appropriate safety precautions.

**For your safety, discharge your battery as much as possible before disassembling your device.** This can be done by disconnecting the AC adapter and allowing the battery to drain. Draining the battery reduces the risk of a dangerous thermal event if the battery is accidentally damaged during the repair. If your battery is swollen, [take appropriate precautions](#).



### TOOLS:

- [Phillips #000 Screwdriver](#) (1)
- [T4 Torx Screwdriver](#) (1)



### PARTS:

- [Dell XPS 13 9365 Replacement Battery](#) (1)

## Step 1 — Battery



- Use a Torx T4 screwdriver to remove the eight screws (M2x3) that secure the base cover to the palm-rest assembly.

## Step 2




- Use your fingertips to lift the system badge open and reveal the single case screw.
- Use a Phillips #000 screwdriver to remove the screw (M1.6x4) that secures the base cover to the palm-rest assembly.

### Step 3



- Starting from the front corner of the computer, pry up the base cover using a spudger and lift the base cover off the palm-rest assembly.


### Step 4



- Disconnect the battery cable from the system board.




## Step 5




- Use a Phillips #000 screwdriver to remove the two screws (M1.6x4) that secure the battery to the palm-rest assembly.

## Step 6



- Use a Phillips #000 screwdriver to remove the six screws (M2x3) that secure the battery to the palm-rest assembly.

## Step 7



- Lift the battery off the palm-rest assembly.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers community](#) for help.