




Lenovo Yoga 720 Bottom Cover Replacement

This guide shows how to remove/replace the bottom cover

Written By: Aiden Baker



INTRODUCTION

This guide shows how to properly remove the bottom case.



TOOLS:

- [T5 Torx Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Lenovo Yoga 720 lower cover](#) (1)

Step 1 — Bottom Cover



- i** Before you begin, be sure to turn off your laptop and discharge the battery down to 25%.
- i** Start by flipping the device over so that you see the screws.
 - Remove seven Torx T5 short screws.
 - Remove three Torx T5 long screws.

Step 2



- Starting from the USB port, use your opening tool to gently pry up the case.
- i** Make sure you are prying on the cover itself, not the metal shield around the USB port.
- Pry along the laptop in the order shown by the arrows.
- i** Do NOT pry along the top side, or you risk damaging the casing. Stay with the arrows.

Step 3



- Lift the case from the bottom side. NOT the side with the hinges.
 - ⚠ When you feel resistance, do NOT keep lifting or you will damage the housing.
- Once you feel resistance, gently pull the case towards you. (away from the hinges.)
- Remove the case.

To reassemble your device, follow these instructions in reverse order.