



Google Pixelbook Battery (Back Panel) Replacement

How to replace a Google Pixelbook battery.

Written By: Megan Phillips



INTRODUCTION

In this guide, you will learn how to remove the back panel of the Google Pixelbook in order to replace the battery. Since the back panel is heavily adhered to the batteries, it is near impossible to remove them without causing damage. We strongly recommend purchasing a whole new back panel/battery pack instead of attempting to separate them.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Metal Spudger \(optional\)](#) (1)
 - [T3 Torx Screwdriver](#) (1)
 - [T5 Torx Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Battery (Back Panel)



- Use the iFixit opening tools or a metal spudger to pry the rubber covers off the back of your Pixelbook.
- Peel the linings off completely until the back of the Pixelbook looks bare.

Step 2




- Remove the two yellow 2.0mm screws by using a T3 Torx screwdriver.

Step 3



- Remove the seventeen 3.0mm T5 Torx screws from the bottom panel.

Step 4



- Use the nylon spudger to pry the edge of the Pixelbook up until you can grab the edge with your fingers.
- Open the back panel completely and lay it flat so you see the whole inside of the computer.

Step 5



- Remove the yellow 2.0mm screw from the middle of the panel by using the T3 Torx screwdriver to turn the screw counterclockwise.

Step 6



- Remove the small, black casing by using the spudger to lift it up from its place.

Step 7



- Disconnect the flat, black cord from the main component by using a spudger to push it out of the slot, or by using your hand to carefully pull it out.
- Your back panel is now free from the main component.

To reassemble your device, follow these instructions in reverse order.