



# Acer Aspire E5-573G Hard Drive Replacement

A short guide on how to replace the hard drive on the Acer Aspire E5-573G.

Written By: Alex Bahm



## INTRODUCTION

Hard drives store all your data, but they are slow and can fail. This guide will show you how to replace a broken or slow hard drive with a different hard drive or solid state drive.


### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Picks set of 6](#) (1)

### PARTS:


- [1 TB SSD / Upgrade Bundle](#) (1)
- [250 GB SSD / Upgrade Bundle](#) (1)
- [500 GB SSD / Upgrade Bundle](#) (1)
- [2 TB SSD](#) (1)

## Step 1 — Optical Drive





- ⚠ Ensure your device is OFF before beginning this procedure.
- Unscrew the 5 mm Phillips head screw holding the drive in place.

## Step 2




- Pull out the disk drive.

### Step 3 — Hard Drive



- Unscrew all 17 (5mm) Philips head screws from the bottom.
- Unscrew the 3 (2.5mm) Philips head screws underneath the optical drive.

### Step 4



- Run a pick around the edge of the laptop (between the two parts) to open it.
- Lift the left side of the case up and unplug the speaker cable before fully taking the bottom off.

## Step 5



- Remove the hard drive by pulling it out to the left.

To reassemble your device, follow these instructions in reverse order.