



# Wolf Gourmet WGBL100S O-ring Replacement

This is guide for replacing the O-ring of a Wolf Gourmet High-Performance Blender.

Written By: Luke Kutz



## INTRODUCTION

If your blender is leaking or making strange noises, consider replacing the O-ring.



### TOOLS:

- [54 Bit Driver Kit](#) (1)
- H4.0
- [Slip Joint Pliers](#) (1)
  - [Adjustable Wrench](#) (1)
  - [Flathead Screwdriver](#) (1)
  - [Tweezers](#) (1)



### PARTS:

- [Wolf Blender O-Ring](#) (1)

## Step 1 — Blender Blades



- Flip over the pitcher to expose the base of the blade assembly.
- Using the H4.0 Allen key from the 54 bit driver kit, attached to an impact driver, remove the socket head cap screw from the drive coupling.
- ⓘ Apply a solvent to remove adhesive if necessary.

## Step 2




- Using a pair of pliers, pull of the drive shaft coupling.

### Step 3



- Using a flat head screwdriver and a mallet, bend down the two tabs holding the large nut.

### Step 4



- Remove the nut using a crescent wrench.

## Step 5



- Push the blade assembly into the jar.
  - Remove the blades from the device.
- ⚠ Be careful not to cut yourself when handling the blades.

## Step 6 — O-Ring



- Use tweezers to pull off the o-ring.

⚠ Be careful not to cut yourself while handling the blender blades.

To reassemble your device, follow these instructions in reverse order.