



Screen Door Mesh Replacement

Learn how to replace the mesh on your screen door.

Written By: Geoff Wacker



INTRODUCTION

Save yourself some money by replacing your screen door mesh with this guide. **This guide assumes that you've already removed the old mesh and spline.**

TOOLS:

- [Flathead Screwdriver](#) (1)
- [iFixit Tech Knife](#) (1)
- [Utility Scissors](#) (1)
- [Screen Rolling Tool](#) (1)

PARTS:

- [Fiberglass Screening](#) (1)
- [Screen Spline](#) (1)

Step 1 — Mesh



- Place the screen door on a completely flat surface. Lay the new screen across the frame.
- ⓘ Make sure that the mesh overlaps on all sides of the frame — you want to have a bit of extra material on every side.
- Use tape or clamps along the bottom edge of the screen to keep it taut against the frame.
- ⓘ If the mesh isn't secured properly, it may become uneven or bunched up during the replacement.

Step 2



- Use the convex (pointy) edge of the screen rolling tool to gently push the mesh into the frame channel along the top of the frame. This will create a crease for the spline to be inserted into.

Step 3



- Use a pair of scissors to make a diagonal cut at the corner of the frame. This will give the mesh some "relief", and prevent it from bunching up in the corners.
- ⓘ Make sure to cut only up until the corner of the channel frame. You do not want to accidentally cut a hole in your new mesh.

Step 4




- Start the spline in the top corner by pressing it into the frame channel with your fingers. Don't worry about getting it fully inserted — the screen rolling tool will handle the rest.

Step 5



- Use the convex (grooved) edge of the screen rolling tool to press the spline into the frame channel. Make sure to keep the screen taut while doing this.
- ⓘ You may need to roll the tool back and forth over the spline a few times to get the spline properly seated.

Step 6



- When you reach the corner, use your hands to route the spline around the corner.
- ⓘ Make sure that the spline doesn't get bunched up at the corner. It's important for the spline to be taut around the entire frame.

Step 7



- Once you reach the bottom (taped) edge, partially remove the tape to make another diagonal cut in the mesh.

Step 8





- Remove the tape section by section, and continue creasing and pressing the spline into the frame channel.
- Keep working in the same manner until you reach your starting point.

Step 9



- Once you reach your starting point, trim the spline so that it will fit snugly up against the beginning edge of the spline without any overlap.

Step 10



- The screen rolling tool does a great job of getting the spline into the frame channel, but it doesn't always get the spline fully inserted. Carefully use a flathead screwdriver to push the spline into the frame channel until it is snug.

⚠ Take your time with this, because an improperly inserted spline may cause the screen to become slack—or a slip with the screwdriver can introduce a hole to your new mesh.

Step 11



- Carefully use a utility knife to trim the excess mesh around the frame. You can use the outer edge of the channel and spline as a guide to get a straight, clean cut.

To reassemble your device, follow these instructions in reverse order.