


Handspring Visor Edge Battery Replacement

Follow this guide to replace the battery of...

Written By: Christian Valoria



INTRODUCTION

Follow this guide to replace the battery of your Handspring Visor Edge.

TOOLS:

Phillips #00 Screwdriver (1) Spudger (1) Tweezers (1)

Step 1 — Flip Cover






- Open the Visor Edge and place it on a table facing down.
- Gently push the tab connecting the flip cover (top half) to the PDA (bottom half) upward to detach them.

 \triangle Do not pull on the flip cover in an attempt to remove it from the PDA.

Step 2 — Back Panel



 Remove the six 4.1 mm Phillips screws from the back plate using the #00 Phillips Scewdriver.

Step 3



• Remove the gray back plate from the PDA.




- Remove the four 2.6 mm Philips screws that are on the sides of the frame.
- Remove the 3.9 mm Philips screw holding the stylus holster to the frame.

Step 5




• Remove the four 2.6 mm Philips screws on the top and bottom of the frame.




• Gently remove the white frame from the back of the PDA.

Step 7 — Battery




• Gently pull off the front cover.





- Using your finger or tweezers, carefully push back the brown lock holding the ribbon cable located at the side of the circuit board.
- Remove the ribbon cable with tweezers.

Step 9



- Using the tweezers, pull back the ribbon cable on the top of the device.
- ⚠ Pull at the white part of the ribbon to avoid tearing.




 Using the same technique as with the other ribbons, locate and remove the ribbon cable above the battery pack.

Step 11




- (i) All the ribbon cables should be disconnected from the mother board.
- Remove the four 3.6 mm Phillips #00 screws located at each corner of the device.






- Carefully separate the circuit board and the screen.
- ⚠ Be careful not to break the soldered wires that connects the circuit board to the battery pack.
- Remove the wire that connects the battery pack to the motherboard using tweezers.

Step 13





• Wedge the spudger under the battery to pry it apart from the adhesive.

