




GoPro Hero 3+ Silver Edition Motherboard Replacement

Are the circuits of your GoPro's motherboard...

Written By: Blake Ehlers



INTRODUCTION

Are the circuits of your GoPro's motherboard fried from water damage? This guide provides steps on how to replace a GoPro Hero 3+ Silver Motherboard and get your camera back in working condition.

TOOLS:

[Tweezers](#) (1)
[Phillips #00 Screwdriver](#) (1)
[iFixit Opening Tool](#) (1)

PARTS:

[GoPro Hero3+ Silver Front Panel](#) (1)
[GoPro Hero3+ Silver Image Sensor](#) (1)
[GoPro Hero3+ Silver Motherboard](#) (1)

Step 1 — Battery




- Push the tab on the back of the device left to remove the plate covering the battery.

Step 2




- Use the strip of tape on the battery to remove the battery from the housing.

Step 3 — Front Panel





- Insert a plastic opening tool in between the front face plate and the black housing.
- ① Make sure you insert the plastic opening tool next to the microSD card slot. There is a small gap that will help separate the face plate.

Step 4



- Continue to use the plastic opening tool and separate the front face plate from the rest of the device.
- ⓘ There is adhesive that helps attach the front face plate. Some extra prying may be required to separate the face plate, but do not use excessive force.



Step 5 — Image Sensor



- Locate the four 8.1mm PH00 screws on the corners of the GoPro and unscrew them using the phillips screwdriver.
- Gently remove the motherboard by using a plastic opening tool to pry it out of the housing.


⚠ Be careful not to damage the ribbon cable connected to the GoPro housing and motherboard.

Step 6





- Remove the ribbon cable by carefully flipping the black clip up with the plastic opening tool and pulling the cable out.

Step 7




- Remove the four 4mm PH00 screws attaching the image sensor to the motherboard with your screwdriver.

Step 8




- Pry off the last ribbon cable with a plastic opening tool.
- Remove the image sensor from the motherboard.

Step 9 — Motherboard



- Remove the single 3.2mm PH00 screw with your screwdriver to detach the motherboard from the mid frame.

Step 10



- Use a plastic opening tool to gently separate the LCD ribbon cable from the motherboard.
- Gently remove the motherboard from the midframe using [tweezers](#).

⚠ Remove motherboard by lifting from the edges. This will reduce the chance of damaging components on the motherboard.

To reassemble your device, follow these instructions in reverse order.