

2009-2015 Toyota Prius Rear Brake Pad and Rotor Replacement

A video tutorial on how to change the rear brake pads and rotor on a 2009-2015 Toyota Prius.

Written By: eCuration



This document was generated on 2020-11-23 09:37:06 PM (MST).

INTRODUCTION

If you are experiencing poor braking performance and or a noise when braking, then it may be time to replace the rear brake pads and or rotor.

Follow this video tutorial by YouTuber <u>NutzAboutBolts</u> to complete the replacement yourself.

Depending on the Toyota Dealership Parts & Service Department; 3M Silicone Paste, 3M Copper Anti-Seize, Sil-Glyde or the Toyota caliper guide pin and anti-seize/squeal grease are recommended respectively.

Torque specs:

- 26 ft. lbs Caliper sliding pin bolts
- 42 ft. lbs Caliper bracket bolts
- 76 ft. lbs Wheel lug nuts

Safety

If this is your first time working on a vehicle read our safety tips before proceeding.

TOOLS:

- Hydraulic Floor Jack (1)
- Jack Stand (1)
- Wheel Chocks (1)
- 3/8" Drive Ratchet (1)
- 14mm socket (1)
- 14mm Wrench (1)
- Drive Disc Brake Piston Tool (1)
- Anti-Seize Lubricant (1)
- Torque Wrench (1)
- 17mm Bike Wrench (1)
- Sil-Glyde Lubricant (1)
- 21mm Socket (1)

PARTS:

- Rear Brake Pads (1)
- Brake Rotor (1)

This document was generated on 2020-11-23 09:37:06 PM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-23 09:37:06 PM (MST).